

4.1.7 Output Configuration

Select the range from the table below and set Switch S3 to the required values.

Switch S3 - Output Configuration												
1	2	3	4	5	6	7	8	9	10	11	12	
	0	1	0	1	0	mA Source			0	Normal		
	1	0	1	0	0	mA Sink			1	Inverted o/p		
	0	1	0	1	1	Voltage						
	0 Buttons Disabled						0	0	0	1 sec		
	1 Buttons Enabled						0	0	1	2 sec		
							0	1	0	5 sec		
							0	1	1	10 sec		
							1	0	0	30 sec		
							1	0	1	1 min		
							1	1	0	5 min		
							1	1	1	10 min		
										4-20mA / 2-10V		
										0-20mA / 0-10V		
										0-10mA / 0-5V		
										2-10mA / 1-5V		
										0	0	
										0	1	
										1	0	
										1	1	

Front panel buttons can be disabled to allow tamper-proof operation of the unit

Averaging time

Examples:

Switch S3 Examples												
	1	2	3	4	5	6	7	8	9	10	11	12
4-20mA Source	1	0	1	0	1	0	0	0	0	0	0	0
0-20mA Source	1	0	1	0	1	0	0	0	0	0	0	1
0-10V	1	0	1	0	1	1	0	0	0	0	0	1
4-20mA Sink	1	1	0	1	0	0	0	0	0	0	0	0



! WARNING !
DO NOT OPEN UNIT OR ADJUST SWITCHES WITH POWER SUPPLY, INPUT OR OUTPUT CONNECTED